Autonics

PHOTOELECTRIC SENSOR

BR SERIES

CE



Thank you very much for selecting Autonics products. For your safety, please read the following before using.

Caution for vour safetv

XPlease keep these instructions and review them before using this unit.

XPlease observe the cautions that follow:

★ Warning Serious injury may result if instructions are not followed.

Product may be damaged, or injury may result if instructions are not followed.

XThe following is an explanation of the symbols used in the operation manual. ▲ caution: Injury or danger may occur under special conditions.

Marning Marning

1. In case of using this unit with machinery(Ex: nuclear power control, medical equpment, ship, vehicle, train, airplane, combustion apparatus, safety device, crime/disaster prevention equipment, etc) which may cause damages to human life or property, it is required to install fail-safe device.


It may cause a fire, human injury or damage to property

⚠ Caution

- 1. This unit shall not be used outdoors.
- It might shorten the life cycle of the product or give an electric shock.
 Use this product inside only. Do not use the product outdoors or location subject to temperatures or humidity outside.(Ex: rain, dirty, frost, sunlight, condensation, etc.)

 2. Do not use this unit where there is flammable or explosive gas.
- It may cause a fire or explosion
- 3. Please observe the rated voltage and do not suppy AC power. It may shorten the life cycle or damage to the production
- 4. Please check the polarity of power and wrong wiring. It may result in damage to this unit.
- 5. Do not use this unit in place where there is vibration or impact.
- t may result in product damage.
- 6. In cleaning the unit, do not use water or an oil-based detergent. It might cause an electric shock or fire that will result in damage to the product.

Ordering information



Operation mode

Operation mode	Light ON	Dark ON		
Receiver operation	Received light Interrupted light			
Operation indicator (LED)	ON OFF			
Transistor output	ON OFF			

- XThe transistor output will be held OFF for 0.5 sec. after supplied power in order to prevent
- malfunction of this photoelectric sensor(Except through-beam type).

 XIf the control output terminal is short-circuited or flows beyond the rated current, the control signal will not be output normally due to protection circuit.
- *The above specifications are subject to change without notice

Specifications


type	sing	Diffuse reflective					Narrow beam reflective		flective	Through-beam			
	BRP100 -DDT	BR100 -DDT	BRP400 -DDT	BR400 -DDT	BRP200 -DDTN	BR200 -DDTN	BRP3M -MDT	BR3M -MDT	BR4M-TDTD BR4M-TDTD-P	BR4M-TDTL-P			
Model		BRP100 -DDT-P	BR100 -DDT-P	BRP400 -DDT-P	BR400 -DDT-P	BRP200	BR200 -DDTN-P	BRP3M -MDT-P	BR3M -MDT-P	BR20M-TDTD BR20M-TDTD-P	BR20M-TDTL BR20M-TDTL-P		
Sensir	ng distance	100mm ^{×1} 400mm ^{×2}			200mm ^{×2}		0.1 to 3m ^{×3}		4m, 20m				
Sens		Translucent, Opaque mater			materia	Opaque materials of min. ø60mm			Opaque materials of min. ø15mm				
Hyst	eresis	Max. 2	0% at ra	ated set	ting dist	ance		_					
Resp	onse time	Max. 1	ms										
Powe	er supply	12-24VDC ±10%(Ripple P-P: Max. 10%)											
Curr	ent umption	Max. 45mA											
Light	t source	Infrared LED(940nm) Infrared LED(850nm) Red LED(660nm)						(660nm)	Infrared LED(850nm)				
Sensitivity adjustment		Adjustable(VR)								Fixed			
Opera	tion mode	Selecta	able Lig	ht ON o	r Dark (ON by c	ontrol c	able(Wh	nite)	Dark ON	Light ON		
Cont outp		NPN open collector output = Load voltage: Max. 30VDC, Load current: Max. 200mA, Residual voltage: Max. 1V PNP open collector output = Output voltage: Min. power voltage-2.5V, Load current: Max. 200mA											
Protec	ction circuit	Reverse polarity protection circuit, Output short-circuit protection circuit											
Indicato	cator	Operation indicator: Red LED, Power indicator: Red LED(only for emitter of through-beam typ											
Con	nection	Outgoing cable											
Insulation resistance		Min. 20MΩ (at 500VDC megger)											
Noise resistance		±240V the square wave noise(pulse width: 1μs) by the noise simulator											
	ctric strength		AC 50/6										
Vibration		1.5mm amplitude at frequency of 10 to 55Hz(for 1 min.) in each of X, Y, Z directions for 2 hour											
Shoo		500m/s	s² (500	6) in X, `	Y, Z dire	ections	for 3 tim	es					
ment	Ambient Ilumination	Sunlight: Max. 11,000/x, Incandescent lamp: Max. 3,000/x(Receiver illumination)											
Nic to	Ambient emperature	-10 to 60°C, Storage: -25 to 75°C											
					e: 35 to	85%RI	1						
Prote	ection	IP66(IE	EC stan	dard)									
Material		•Case ☞ BRP: PA(Black) BR: Brass, Ni-plate •Sensing part ☞ PC					Ni-pla	M: PA)/ : Brass, te g part ==	•Case ☞ Bra: •Sensing part =				
Cabl	le	ø5mm, 4P, Length: 2m(Emitter of through-beam type: ø5mm, 2P, Length: 2m / Receiver: ø 5mm, 3P, Length: 2m (AWG 22, Core wire diameter: ø0.08, Number of core wire: 60, Insulator out diameter: ø1.2)											
	Separate	VR adjustment driver Reflector(MS-2)											
Acce-													
Acce- ssory	Common	BR: Fix	king Nu	ts, Wasl	ner / BR	P: Fixin	g Nuts						

- *The temperature or humidity mentioned in Environment indicates a non freezing or condensation environment
- X1: Non-glossy white paper 50×50mm
 X2: Non-glossy white paper 100×100mm.
 X3: Sensing distance and sensing target for Retroreflective type is rated based on reflector(MS-2). Sensing distance indicates possible reflector setting range. Sensing under 0.1m is also available.


Dimensions

CE

Approval



•BR4M-TDTD / BR4M-TDTD-P / BR4M-TDTL / BR4M-TDTL-P BR20M-TDTD / BR20M-TDTD-P / BR20M-TDTL / BR20M-TDTL-P




Lens

M18×1


Material: PA(Black)


Connections



Control output circuit diagram


●NPN open collector output






PNP open collector output

Caution for using





**Before using this unit, select Light ON/Dark ON with control cable.(Light ON: Connect control cable with 0V/Dark ON: Connect control cable with +V) *Control cable is only for Diffuse reflective/Narrow beam reflective/Retroreflective type

target

Min.

Adjust

Right/Left

30° to 45°

Optical axis

SENS

Installation and sensitivity adjustment

Please supply the power to the sensor, after setting the emitter and the receiver in face to face, and then adjust an optical axis and the sensitivity as follow;

Diffuse reflective/Narrow beam reflective

- 1. Even though the sensor is still available at the max. sensitivity position, it is recommended to adjust sensor sensitivity with considering existence of reflective material in background.
- 2. Set the target at a position to be detected by the beam, then turn the adjuster until point (a) which the indicator turns on from Min. position of the adjuster. 3. Take the target out of the photoelectric sensor, then turn the
- adjuster until point (b) which the indicator turns ON. [If the indicator does not turn on, max, position is point (b).
- 4. Set the adjuster at the center of two switching point ⓐ, ⓑ XThe sensing distance indicated in the specification chart is for non-glossy white paper 100×100mm or 50×50mm. It is subject to change depending on the size of sensing target, surface status and gloss, etc.

Retroreflective


- Set the sensor and reflector(MS-2) in opposite each other and supply the power. 2. Check stable indicator operation range with moving both senso
- and reflector up/down and right/left and adjust the position in After finishing position adjustment, check whether the sensor is operated normally with placing a sensing target on optical axis.
- XIn case of using multiple sensors in parallel, keep each sensor's distance min. 30cm. XIn case sensing target has higher reflectivity than non-glassy white paper, the sensor may cause malfunction due to direct reflected light from the target. Keep certain distance between a sensor and sensing target, or install the sensor with making

sensing target's surface inclining 30° to 45° to photo sensor's

XSensitivity adjustment: Please see the diffuse reflective /narrow beam reflective type.

Through-beam

- 1. Set the receiver and emitter in opposite each other and supply the power.
- 2. Check stable indicator operation range with moving both receiver and emitter up/down and right/left and adjust the position in the
- 3. After finishing position adjustment, check whether the sensor is operated normally with placing a sensing target on optical axis.
- XIf the sensing target is translucent body or smaller than ø 15, it might not detect the target cause light passed.



Optima

(MS-2

Reflecto

Adjust Up/Down

Up/Down


- 1. Intercept a strong source or light as like suringit, spotlight within inclination angle range of photoelectric sensor.

 2. The photoelectric sensor may cause malfunction under the fluorescent lamp light, so be sure to use cut-off light with panel.

 3. When more than 2 sets of Through-beam type sensor are used closely, it might cause interference each other. Be sure to put enough space between them in order to avoid
- malfunction.
- When more than 2 sets of diffuse reflective/narrow beam reflective type are installed adjacently, it can occur malfunction by light beam from the other target. So it must be installed
- at an enough interval. 5. If photoelectric sensor is installed at flat part, it might cause malfunction by reflection light
- from flat part. Be sure to put space between photoelectric sensor and ground.

 6. When wiring the photoelectric sensor with high voltage line, power line in the same conduit, it may cause malfunction or mechanical trouble. Therefore please wire separately or use different conduit.
- 7. Avoid installing the unit as following place. Corrosive gas, oil or dust, strong flux, noise, sunlight, strong alkali, acid.
- B. In case of connecting DC relay as inductive load to output, please remove surges by using diode or varistor.

 9. The photoelectric sensor cable shall be used as short as possible, because it may cause
- The photocecuric serious cable shall be used as short as possible, because it may cause malfunction by noise through the cable.
 When it is stained by dirt at lens, please clean the lens with dry cloth, but do not use an organic materials such as alkali, acid, chromic acid.
 When using switching power supply as the source of supplying power, F.G. terminal shall be grounded and condenser for removing noise shall be installed between 0V and F.G. terminal.



12. Installation environment ①It shall be used indoor ②Altitude max. 2,000m ③Pollution degree 2 ④Installation categoryII XIt may cause malfunction if above instructions are not followed.

Major products



- Door/Door side sensors Pressure sensors ■ Rotary encoders Display units
- Power controllers Sensor controllers Panel meters ■ Graphic/Logic panels ■ Temperature controllers
 ■ Field network devices
- Switching power supplies
- Temperature/Humidity transducers ■ Tachometer/Pulse(Rate) meters

- Stepping motors/drivers/motion controllers ■ Laser marking system(CO₂, Nd:YAG)
- Laser welding/soldering system



EP-KE-08-0050K